

# Amp Models List\*

| No. | Name      | Based On                   | Cab Sim (Not shown in Binary Amp) |
|-----|-----------|----------------------------|-----------------------------------|
| 1   | FRED HBE  | Friedman BE100             | FRED 4x12                         |
| 2   | RECT LEAD | Mesa/Boogie Dual Rectifier | RECT 4x12                         |
| 3   | CHEF CLN  | Matchless Chieftain        | CHEF 2x12                         |
| 4   | USA 2C+   | Mesa/Boogie Mark II C+     | RECT 4x12                         |
| 5   | DARK DUO  | Fender '65 Twin Reverb     | DARK 2x12                         |
| 6   | DIZZ VH   | Diezel VH4                 | DIZZ 4x12                         |
| 7   | BASS CLN  | Fender '59 Bassman         | BASS 4x10                         |
| 8   | AREA 51   | Peavey 5150                | AREA 2x12                         |
| 9   | BRIT J45  | Marshall JTM45             | BRIT 4x12                         |
| 10  | SAGA 120  | ENGL Savage 120            | SAGA 4x12                         |
| 11  | BRIT 800  | Marshall JCM800            | BRIT 4x12                         |
| 12  | TWD LUX   | Fender Tweed Deluxe        | TWD 1x8                           |
| 13  | SOLO 100  | Soldano SLO 100            | SOLO 4x12                         |
| 14  | VOXY T30* | Vox AC30 Top Boost         | VOXY 2x12                         |
| 15  | OGRE A30  | Orange AD30                | OGRE 4x12                         |
| 16  | JAZZ TWIN | Legendary Jazz Clean amp   | JAZZ 2x12                         |

\*1. The Manufacturers and product names mentioned above are trademarks or registered trademarks of their respective owners. The trademarks were used merely to identify the sound character of the products.

2. The MIDDLE knob cuts the effect presence (the screen shows CUT when adjusting) on VOXY T30.